

Calibration Procedure - KM820/V

Verifying Infra-Red Non contact thermometers

- Insert the reference thermometer probe (e.g. KM20Ref) fully into one of the holes in the Validator.
- Allow the instruments to stabilise to environment conditions.
- Switch on both instruments after stabilisation period.
- Point the Infra-Red thermometer at the base of the Validator while ensuring the nozzle is as far inside the Validator cup as is possible. Note the variation. (acceptable error 2.5°C)

Verifying Contact Thermometers

- Insert the reference thermometer probe (e.g. KM20Ref) fully into one of the holes in the Validator.
- Insert the probe of the Instrument being verified fully into the other hole in the Validator.
- Allow the instruments to stabilise to environment conditions.
- Switch on both instruments after stabilisation period.
- Note the variation. The acceptance error will be dependent on the specification of the unit being verified.

Note: The time for the instruments to stabilise will be dependent on the validator reaching its environment temperature, which at freezer temperatures could be up to 2 hours.



Care must be exercised when handling the validator after exposure to low temperatures.



COMARK

A Fluke Company

Comark Instruments,
52 Hurricane Way,
Norwich, Norfolk NR6 6JB England
Telephone: 01603 (+44 1603) 256647
Fax: 01603 (+44 1603) 256744

Stock No. 17064 Issue 5
© Comark Instruments